

Command Line Interface Guide

www.qntmnet.com



Copyright Information

The copyright and trademark specifications mentioned in this document are subject to change without prior notice. All the content, including the Quantum Networks[®] logo, is the property of Zen Exim Pvt. Ltd. Other brands or products mentioned in this document may be trademarks or registered trademarks of their respective owners. It is strictly prohibited to use, translate or transmit the contents of this document in any form or by any means without obtaining prior written permission from Zen Exim Pvt. Ltd.



Document Abstract

This document describes the use of Command Line Interface, here in after referred as CLI through SSH to access the Access Point parameters, configuration and offers several troubleshooting tools.



Prerequisites

In order to access device using CLI, SSH supported utility is required. CLI access is operating system independent. You may use Windows[®] or MAC[®] or Linux[®]. The command terminal should support SSH. In Windows[®], you may use third party application like Putty whereas the MAC[®] and Linux[®] command terminals already support SSH. Default port used by SSH is 22. **Please use the same device username and password as defined during Site creation in Quantum Rudder (https://cc.qntmnet.com)** and for standalone use preconfigured device login username and password. We used **admin** as the Device username and **192.168.25.6** is the Access Point IP address.

Example of a SSH command (IP Address 192.168.25.6 has been used in test scenario only): command_prompt>**sshadmin@192.168.25.6** {press Enter Key}

How to access CLI?

Using Windows® platform?

Step 1: Download Putty for windows and follow as below (For test scenario we used 192.168.25.6 as the assigned IP address to Access Point).

8	PuTTY Configuration	? ×
Category:		
Session	Basic options for your PuTTY se	ession
	Specify the destination you want to conne	ect to
En reminal	Host Name (or IP address)	Port
Bell	192.168.25.6	22
Features ⊡ Window	Connection type: ○ Raw ○ Telnet ○ Rlogin ● SSF	H O Serial
Appearance Behaviour Translation Selection	Load, save or delete a stored session Saved Sessions	
Colours	Default Settings	Load
Data		Save
···· Telnet		Delete
Riogin		
Serial	Close window on exit: Always Never Only on c	lean exit
About Help	Open	Cancel



Step 2: On first connection from Windows[®] using Putty, click "Yes" to accept host key.

PuTTY Security Alert	×
The server's host key is not cached in the registry. You have no guarantee that the server is the computer you think it is. The server's rsa2 key fingerprint is: ssh-rsa 2048 73:fc:a7:e5:b3:83:1a:c1:63:d7:71:dc:45:ee:9b:af If you trust this host, hit Yes to add the key to PuTTY's cache and carry on connecting. If you want to carry on connecting just once, without adding the key to the cache, hit No. If you do not trust this host, hit Cancel to abandon the connection.	
Yes No Cancel Help	

Step 3: Enter the username and password defined during Site creation in Quantum Rudder and press Enter.

B	192.168.25.6 - PuTTY -	. 🗆 🛛 🗙
login as: admin admin@192 168 25 6's password:		
admingif2.100.20.0 5 password.	•	



Step 4: You are successfully logged into Access Point with command prompt as "QNTM". You may execute CLI commands now.

🧬 192.168.25.6 - PuTTY –	×
W I R E L E S S W O R L D	^
Quantum Networks (QNOS , 121173000056)	

QNTM >	
	\sim

For Linux[®] and Apple[®] devices, SSH is, by default, supported. In usual cases any third party application is not required.

Using Apple® Platform?

We used an Apple[®] Macbook with macOS High Sierra Version 10.13.4 to brief commands ahead. Feel free to consult for updated versions issued ahead.

Step 1: Start Terminal and execute below SSH command followed by Enter key (For test scenario we used 192.168.25.6 as the assigned IP address to Access Point).

	a dennis –		
st login: Sun May 27 20:52:47	on ttys000		
cbook:~ dennis\$ ssh admin@192.	168.25.6		



Step 2: For first connection to the Access Point using SSH, you may be prompted to accept the host key. Do so by clicking "Yes" and press Enter.



Step 3: Please enter the password as defined to access the Access Point during **Site** creation in Quantum Rudder and press Enter.



Step 4: You are successfully logged into Access Point with command prompt as "QNTM" (Device Name). You may execute CLI commands now.

• •	dennis — ssh admin@192.168.25.6 — 100×30
	WIRELESS WORLD
	Quantum Networks (QNOS , 121173000056)

QNTM >	I

Understanding Commands:

General Commands:

Command Prompt > help ∉

Description: **help** command would display basic commands available through terminal.

QUANTUM

• • •	👔 dennis — ssh admin@192.168.25.6 — 80×24	
QNTM > help]
?	: To view all commands.	
exit	: To exit from ssh.	
clear	: To clear display.	
restart	: To restart your QNAP.	
reset	: To reset your QNAP.	
QNTM >		

Command Prompt >?∉

Description: ? command would display all (except basic) commands available through terminal.

• •	👔 dennis	— ssh admin@1	92.168.25.6 — 80×	24	
****** (W I R E L E *********************************	SSWORL ************************************	D ************************************		E
QNTM > ? ? interface setwan wanstatus QNTM >	clear nslookup statistics wclient	date ping status	exit reset sysinfo	help restart tracert]



Command Prompt > clear ∉

Description: **clear** command would clear the terminal screen.

• • •	👚 dennis — ssh admin@192.168.25.6 — 80×24	
QNTM > help] E
? exit clear restart reset	: To view all commands. : To exit from ssh. : To clear display. : To restart your QNAP. : To reset your QNAP.	
QNTM > clear		

Command Prompt > date∉

Description: **date** command would display current date and time in Access Point. Date and Time can't be modified from Terminal as they are automatically updated as per selected Country in Quantum Rudder or in standalone configuration.





Description: **ping** command can be used in trouble shooting network issues and helps to verify IP-level connectivity. When troubleshooting, you can use this command to send an ICMP echo request to a target host name or IP address. Use it whenever you need to verify that the Access Point can connect to the network resources.

🖲 🗢 💼 dennis — ssh admin@192.168.25.6 — 100×30
W I R E L E S S W O R L D ***********************************
QNTM > ping www.google.com
Pine www.google.com (172.217.26.196); 50 data bytes 64 bytes from 172.217.26.196; seget til=52 time=160.210 ms
64 bytes from 172.217.26.196: seq=1 ttl=52 time=276.442 ms
64 bytes from 172.217.26.196: seq=2 ttl=52 time=139.546 ms
64 bytes from 172.217.26.196: seq=3 t1=52 time=1691.778 ms
64 bytes from 1/2.21/.20.190; seq=4 (t1=02 (time=205.342 ms
www.google.com ping statistics
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 139.546/506.663/1691.778 ms

Command Prompt > nslookup∛

Description: **nslookup** command can be used during trouble shooting to query domain name server and, if successful, replies with resolved IP Address.



Command Prompt > tracert ↔

Description: **tracert** command can be used during trouble shooting to trace path / hopes from Access Point to the specified destination.

QUANTUM

💿 🕘 🔹 🕜 dennis — ssh admin@192.168.25.6 — 100×30
QNTM > tracert www.google.com
traceroute to www.google.com (172.217.26.196), 30 hops max, 38 byte packets
1 192.168.25.1 (192.168.25.1) 1.646 ms 4.286 ms 92.203 ms
2 172.16.0.1 (172.16.0.1) 1.841 ms 1.683 ms 1.255 ms
3 117.247.238.1 (117.247.238.1) 2.400 ms 3.501 ms 14.174 ms
4 218.248.174.161 (218.248.174.161) 72.292 ms 3.068 ms 65.168 ms
5 218.248.174.174 (218.248.174.174) 10.446 ms 4.301 ms 16.733 ms
6 * 218.248.235.157 (218.248.235.157) 254.449 ms *
7 * * *
8 /4.125.48.138 (/4.125.48.138) 126.109 ms /2.14.19/.4 (/2.14.19/.4) 343./93 ms /2.14.198./3 (
//2.14.196.73) 203.831 ms
9 100.1/0.240.103 (100.1/0.240.103) 410.531 ms 100.1/0.240.194 (100.1/0.240.194) 222.392 ms 10
0.170.240.210 (100.170.240.210) 100.047 ms 10 214 230 41 147 (214 230 41 147) 107 315 mc 108 170 224 237 (108 170 224 237) 343 004 mc 214
230 50 171 (216 230 60 171) 337 275 ms
11 108,170,253,113 (108,170,253,113) 251,743 ms 108,170,253,97 (108,170,253,97) 238,307 ms 53,7
29 ms
12 72.14.237.165 (72.14.237.165) 115.778 ms 178.533 ms 135.198 ms
13 maa03s23-in-f196.1e100.net (172.217.26.196) 83.698 ms 78.038 ms 226.087 ms
QNTM >
_

Command Prompt > restart∉

Description: **restart** command can be used to restart the Access Point through terminal. When prompted, enter **y** to continue reboot or **n** to cancel reboot.





Command Prompt > exit∉

Description: **exit** command can be used to disconnect the terminal access. When prompted, enter **y** to exit or **n** to cancel.



System Commands:

Command Prompt > **setwan** \not

Description: **setwan** command can be used to define Access Point's WAN Interface mode. Available options are DHCP / Static IP or PPPoE. To apply configuration, enter \mathbf{y} or \mathbf{n} to discard.



Command Prompt > wanstatus $\not\!\!\!\!/$

Description: **wanstatus** command would display Ethernet Port status with operation mode (Static / DHCP / PPPoE) along with details.

QUANTUM

🖲 🕘 🔵	🟠 dennis — ssh admin@192.168.25.6 — 100×30
QNTM > wanstatus	
Wan Port :	- ETH0
Proto :	- static
IP :	- 192.168.25.6
Subnet :	- 255.255.255.0
Gateway :	- 192.168.25.1
DNS:	- 192.168.25.1 4.2.2.2
QNTM >	

Command Prompt > interface 4

interface command will display detail listed below

• •			🔒 🔒	ennis — ssh ac	dmin@192.10	68.25.6 — 100×30
QNTM > i	nterface					
Country		:-	IN			
Radio		:-	5 GHz			
Channel	Bandwidth	:-	80 MHz			
Channel	Channel Range :-		auto			
Мах Тх Р	ower	:-	auto			
Radio		:-	2.4 GHz			
Channel	Bandwidth	:-	20 MHz			
Channel	Range	:-	auto			
Max Tx P	ower	:-	auto			
wireless Radio	interface:- SSID		Enable	 Isolation	 Roaming	Encryption
2.4GHz	QNTM_STAFF		Yes	No	Yes	 psk2+aes
5GHz	QNTM_STAFF	i	Yes	No	Yes	psk2+aes
2.4GHz	QNTM_GUEST	i	Yes	Yes	Yes	psk2+aes
5GHz	QNTM_GUEST	1	Yes	Yes	Yes	psk2+aes
QNTM >						

Parameter	Description			
Country	Displays selected country in Access Point.			
Radio	Displays type of Radio (2.4 GHz / 5 GHz)			
Channel Bandwidth	Displays Channel bandwidth configured in Access Point			
Channel Range	Displays configured channel range and Max Tx Power setting in			
Max Tx Power	Access Point			
Radio	Displays type of Radio(2.4 GHz / 5 GHz)			
Channel Bandwidth	Displays Channel bandwidth configured in Access Point			
Channel Range	Displays configured channel range and Max Tx Power setting in			
Max Tx Power	Access Point			

Command Prompt > statistics ${\mathcal A}$

Statistics command will display detail listed below

🖲 🕘 🗧 🏠	dennis — ssh admin@192.168.25.6 — 100×30
QNTM > statistics	
Model No.:- QN-I-200	
SrNo.:- 121173000056	
MAC:- 58:61:63:00:00:56	
Uptime:- 6days-3h:03min	
Cloud Status:- Offline	
Firmware:- QN.1.0.0.0.11	
HostName:- admin	
CPU Utilization(%):- 38.71	
Memory Usage(%):- 85.61	
Total Wireless Clients:- 0	
Clients On 2.4 GHz:- 0	
Clients On 5 GHz:- 0	
Channel of 2.4 GHz :- auto(11)	
Channel_of 5 GHz :- auto(52)	
QNTM >	

Parameter	Description		
Model No	Displays Access Point model number		
Sr. No	Displays Access Point serial number		
MAC	MAC Address of Access Point		
Uptime	Displays since what time Access Point has been Up		
Firmware	Displays current Access Point Firmware detail		
CPU Utilization (%)	Displays Access Point CPU utilization in percentage		
Memory Usage (%)	Displays Access Point Memory utilization in percentage		
Total Wireless Clients	Provides detail of total number of connected clients		
Clients On 2.4 GHz	Displays number of clients connected on 2.4 GHz		
Clients On 5 GHz	Displays number of clients connected on 5 GHz		
Channel 2.4	Displays 2.4 GHz, selected channel detail		
Channel 5	Displays 5 GHz, selected channel detail		

Command Prompt > status∉

status command will display detail listed below.

🖲 😑 🔵	🏠 dennis — ssh admin@192.168.25.6 — 100×30
QNTM > status	
Uptime	:- 6days-3h:08min
Cloud Status	:- Offline
Total Wireless Clients	:- 0
Clients On 2.4 GHz	:- 0
Clients On 5 GHz	:- 0
Channel of 2.4 GHz	:- Auto(11)
Channel of 5 GHz	:- Auto(52)
ЕТНО	:- Up
ETH1	:- Down
ETH2	:- Down
QNTM >	

Parameter	Description			
Uptime	Displays since what time Access Point has been Up.			
Cloud status	Displays Access Point status on Quantum Rudder whether it is online or offline. (If configured in Quantum Rudder)			
Total Wireless Clients	Provides detail of total number of connected clients. (2.4 GHz / 5 GHz both)			
Clients on 2.4GHz	Displays number of clients connected on 2.4 GHz.			
Clients on 5 GHz	Displays number of clients connected on 5 GHz.			
Channel 2.4	Displays 2.4 GHz, selected channel detail.			
Channel 5	Displays 5 GHz, selected channel detail.			
ETHO	Displays reference ethernet port status.			
ETH1	Displays reference ethernet port status.			
ETH2	Displays reference ethernet port status.			

Command Prompt > wclient $\not\in$

wclient command will display detail listed below.

🖲 😑 🔮 👔 dennis — ssh admin@192.168.25.6 — 100×30					
QNTM > wo	client 27.40 VAIO				
RADIO	SSID	MAC	IP	HOSTNAME	
2.4_Ghz 5_Ghz	QNTM_STAFF QNTM_STAFF	84:4B:F5:D2:9E:3B 14:20:5E:88:02:79	192.168.27.40 ?	VAIO ?	
QNTM >			-	-	

Parameter	Description
Radio	Displays radio detail on which reference client is connected.(2.4 GHz / 5 GHz)
SSID	Display SSID with which client is connected.
MAC	MAC address of client device.
IP	IP Address of the client device.
HOSTNAME	Displays Client device hostname.



Command Prompt > reset∉

The **reset** command is used Access Point to factory setup if it's in standalone mode. The terminal will logout from session.

Note: If the access point is managed by Quantum Rudder, reset command will not work. It will give warning.

