



QASA CLI GUIDE

**Commands for QoS and Flow-based
Redirection**

Contents

1. QoS	4
accounting.....	4
class.....	4
class-map	5
clear mls qos statistics.....	6
drop	6
match	7
mls qos aggregate-policy	8
mls qos cos	8
mls qos map	9
mls qos queue algorithm.....	10
mls qos queue wdrr weight	11
mls qos queue wrr weight.....	11
mls qos queue bandwidth	12
mls qos trust.....	13
policy burst.....	13
policy	14
policy aggregate.....	14
policy-map	15
service-policy input.....	15
service-policy input vlan	16
set.....	16
show class-map	17
show policy-map	18
show mls qos interface	18
show mls qos in (interface <interface-name> policy) (vlan <vlan-id>).....	21
show mls qos maps	21
show mls qos vlan.....	23
show mls qos aggregate-policy	23
transmit.....	24
access-group redirect to interface ethernet	24
show flow-based-redirect.....	25
add.....	25
service-policy.....	26

set.....26

1. QoS

accounting

Syntax	accounting no accounting
Parameter	None.
Default	Do not set statistic function.
Mode	Policy map configuration mode.
Usage	Sets statistic function for the classified traffic. After enabling this function, add statistic function to the traffic of the policy class map, the messages can only be red or green when passing policy. When print statistic information in packets means classify packets numbers and not support the classify of color.
Example	Count the packets which satisfy c1 rule. Switch#config Switch(config)#class-map c1 Switch(config-classmap-c1)#exit Switch(config)#policy-map p1 Switch(config-policymap-p1)#class c1 Switch(config-policymap-p1-class-c1)#accounting Switch(config-policymap-p1-class-c1)#exit Switch(config-policymap-p1)#exit Switch(config)#

class

Syntax	class <class-map-name> [insert-before <class-map-name>] no class <class-map-name>
Parameter	<class-map-name> : is the class map name used by the class. insert-before <class-map-name> : insert a new configured class to the front of a existent class to improve the priority of the new class.
Default	No policy class is configured by default.
Mode	Policy map configuration mode.
Usage	Associates a class to a policy map and enters the policy class map mode; the no command deletes the specified class. Before setting up a policy class, a policy map should be created and the

	<p>policy map mode entered. In the policy map mode, classification and next hop configuration can be performed on packet traffic classified by class map.</p>
Example	<p>After add a policy class map c1 to the policy map, add a policy class map c2 and insert it to the front of c1.</p> <pre> Switch(config)#class-map c1 Switch(config-classmap-c1)#exit Switch(config)#class-map c2 Switch(config-classmap-c2)#exit Switch(config)#policy-map p1 Switch(config-policymap-p1)#class c1 Switch(config-policymap-p1-class-c1)#exit Switch(config-policymap-p1)#class c2 insert-before c1 Switch(config-policymap-p1-class-c2)#exit </pre>

class-map

Syntax	class-map <class-map-name> no class-map <class-map-name>
Parameter	<class-map-name> : class map name
Default	No class map is configured by default.
Mode	Global Mode.
Usage	Creates a class map and enters class map mode; the no command deletes the specified class map.
Example	<p>Creating and then deleting a class map named "c1".</p> <pre> Switch#config Switch(config)#class-map c1 Switch(config-classmap-c1)#exit Switch(config)#no class-map c1 </pre>

clear mls qos statistics

Syntax	clear mls qos statistics (interface [ethernet] <interface-name>) (vlan <vlan-id>)
Parameter	<vlan-id> : VLAN ID <interface-name> : interface name
Default	Do not set action.
Mode	Global Mode.
Usage	Clears accounting data of the specified ports or VLAN Policy Map. If there are no parameters, clear accounting data of all policy map.
Example	Clear the Policy Map statistic of VLAN 100. Switch#clear mls qos statistics vlan 100

drop

Syntax	drop no drop
Parameter	none
Default	none
Mode	Policy class map configuration mode.
Usage	Drops the specified packet after configure this command.
Example	Drop the packet which satisfy c1. Switch#config Switch(config)#policy-map p1 Switch(config-policymap-p1)#class c1 Switch(config-policymap-p1-class-c1)#drop Switch(config-policymap-p1-class-c1)#exit Switch(config-policymap-p1)#exit

match

Syntax	<pre>match (access-group <acl-index-or-name> ip dscp <dscp-list> ip precedence <ip-precedence-list> ipv6 access-group <acl- index-or-name> ipv6 dscp <dscp-list> ipv6 flowlabel <flowlabel-list> vlan <vlan-list> cos <cos-list>) no match {access-group ip dscp ip precedence ipv6 access- group ipv6 dscp ipv6 flowlabel vlan cos)</pre>
Parameter	<p><acl-index-or-name> : match specified IP ACL, MAC ACL or IPv6 standard ACL or MAC-IP ACL, the parameters are the number or name of the ACL;</p> <p><dscp-list> : match specified DSCP value, the parameter is a list of DSCP consisting of maximum 8 DSCP values, the range is 0~63;</p> <p><ip-precedence-list> : match specified IP Precedence, the parameter is a IP Precedence list consisting of maximum 8 IP Precedence values with a valid range of 0~7;</p> <p>ipv6 access-group <acl-index-or-name> : match specified IPv6 ACL, the parameter is the number or name of the IPv6 ACL;</p> <p><flowlabel-list> : match specified IPv6 flow label, the parameter is IPv6 flow label value, the range is 0~1048575;</p> <p><vlan-list> : match specified VLAN ID, the parameter is a VLAN ID list consisting of maximum 8 VLAN IDs, the range is 1~4094;</p> <p><cos-list> : match specified CoS value, the parameter is a CoS list consisting of maximum 8 CoS, the range is 0~7;</p>
Default	No match standard by default.
Mode	Class-map Mode.
Usage	<p>Configures the match standard of the class map; the no form of this command deletes the specified match standard.</p> <p>Only one match standard can be configured in a class map. When configuring the match ACL, permit rule as the match option, apply Policy Map action. Deny rule as the excluding option, do not apply Policy Map action. (The deny rule is not supported issuing in PBR, please pay attention to avoid it.) If configure another match rule after one was configured, the operation fails, but configure the same match rule will cover the previous.</p>
Example	<p>Create a class-map named c1, and configure the class rule of this class-map to match packets with IP Precedence of 0.</p> <pre>Switch(config)#class-map c1 Switch(config-classmap-c1)#match ip precedence 0 Switch(config-classmap-c1)#exit</pre>

mls qos aggregate-policy

Syntax	mls qos aggregate-policy <policer_name><bits_per_second> burst-group <normal_burst_bytes> no mls qos aggregate-policy <policer_name>
Parameter	<policer_name> : it is the aggregate policy name. <bits_per_second> : it define the information rate, namely CIR, the unit is kbit per second, and it ranges from 1 to 10000000; <normal_burst_bytes> : it define the committed burst size, namely CBS, the unit is kilobyte, and it ranges from 1 to 8192, when the CBS more than the maximum of chips , it uses the biggest value that chip support to set hardware, CLI have not notice information;
Default	The default is no policy action.
Mode	Global Mode.
Usage	Define an aggregate policy command. The no command deletes mode configuration. It only supports single cylinder configuration, when configuring, if configured CBS, not support configure color. Green packets only supports transmit, red packets only supports drop.
Example	Set 10000 as CIR, CBS is 512. Switch (config)#policy burst 1512 Switch(config)# mls qos aggregate-policy 11000 burst-group 1

mls qos cos

Syntax	mls qos cos <default-cos> no mls qos cos
Parameter	<default-cos> : default CoS value for the port, the valid range is 0 to 7.
Default	The default CoS value is 0.
Mode	Port Configuration Mode.
Usage	Configures the default CoS value of the port; the " no mls qos cos " command restores the default setting. Configure the default CoS value for switch port. In default configuration, the message ingress cos from this port is default value whether the message with tag. If the message without tag, the message cos value for tag is enactment.

Example	<p>Setting the default CoS value of ethernet port 1/0/1 to 7, i.e., packets coming in through this port will be assigned a default CoS value of 7 if no CoS value present.</p> <pre>Switch(config)#interface ethernet 1/0/1 Switch(config-if-ethernet1/0/1)#mls qos cos 7</pre>
----------------	---

mls qos map

Syntax	<pre>mls qos map (cos-intp <intp1..intp8> cos-dp <dp1..dp8> dscp-intp <in-dscp list> to <intp> dscp-dp <in-dscp list> to <dp> dscp-dscp <in-dscp list> to <out-dscp>) no mls qos map (cos-intp cos-dp dscp-intp dscp-dp dscp- dscp)</pre>																																																																																																												
Parameter	<p>cos-intp <intp1..intp8> : defines the mapping from CoS to intp (queue) value, <intp1..intp8> are 8 intp value corresponding to the 0 to 7 CoS value, each intp value is delimited with space, ranging from 0 to 7;</p> <p>cos-dp<dp1..dp8> : defines the mapping from cos to intp (queue), <dp1..dp8> is 8 drop priority and it corresponding to the Cos value from 0 to 7, every drop priority is separated by space, and it ranges from 0 to 2;</p> <p>dscp-intp : defines the mapping from DSCP to intp (queue).</p> <p>dscp-dp : defines the mapping from dscp to drop priority.</p> <p>dscp-dscp : defines the mapping from entrance dscp to export dscp, <in-dscp list> is the input dscp value, the most is 8 and it separated by space from each other, and it ranges from 0 to 63, <out-dscp> is output dscp value and it ranges from 0 to 63.</p>																																																																																																												
Default	<p>Default mapping values are:</p> <p>Default CoS-TO-INTP Map</p> <p>COS: 0 1 2 3 4 5 6 7</p> <p>INTP: 0 1 2 3 4 5 6 7</p> <p>Default CoS-TO-DP Map</p> <p>CoS 0 1 2 3 4 5 6 7</p> <p>DP 0 0 0 0 0 0 0 0</p> <p>Default DSCP-TO-INTP Map</p> <table border="0"> <tr><td>d1:</td><td>d2</td><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td></tr> <tr><td>O:</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>1</td><td>1</td><td>1</td></tr> <tr><td>1:</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>2</td><td>2</td><td>2</td><td>2</td><td>2</td><td>2</td></tr> <tr><td>2:</td><td>2</td><td>2</td><td>2</td><td>2</td><td>3</td><td>3</td><td>3</td><td>3</td><td>3</td><td>3</td><td>3</td></tr> <tr><td>3:</td><td>3</td><td>3</td><td>4</td><td>4</td><td>4</td><td>4</td><td>4</td><td>4</td><td>4</td><td>4</td><td>4</td></tr> <tr><td>4:</td><td>5</td><td>5</td><td>5</td><td>5</td><td>5</td><td>5</td><td>5</td><td>5</td><td>6</td><td>6</td><td>6</td></tr> <tr><td>5:</td><td>6</td><td>6</td><td>6</td><td>6</td><td>6</td><td>6</td><td>7</td><td>7</td><td>7</td><td>7</td><td>7</td></tr> <tr><td>6:</td><td>7</td><td>7</td><td>7</td><td>7</td><td>7</td><td>7</td><td>7</td><td>7</td><td>7</td><td>7</td><td>7</td></tr> </table> <p>Default DSCP-TO-DP Map</p> <table border="0"> <tr><td>d1:</td><td>d2</td><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td></tr> </table>	d1:	d2	0	1	2	3	4	5	6	7	8	9	O:	0	0	0	0	0	0	0	1	1	1	1	1:	1	1	1	1	1	2	2	2	2	2	2	2:	2	2	2	2	3	3	3	3	3	3	3	3:	3	3	4	4	4	4	4	4	4	4	4	4:	5	5	5	5	5	5	5	5	6	6	6	5:	6	6	6	6	6	6	7	7	7	7	7	6:	7	7	7	7	7	7	7	7	7	7	7	d1:	d2	0	1	2	3	4	5	6	7	8	9
d1:	d2	0	1	2	3	4	5	6	7	8	9																																																																																																		
O:	0	0	0	0	0	0	0	1	1	1	1																																																																																																		
1:	1	1	1	1	1	2	2	2	2	2	2																																																																																																		
2:	2	2	2	2	3	3	3	3	3	3	3																																																																																																		
3:	3	3	4	4	4	4	4	4	4	4	4																																																																																																		
4:	5	5	5	5	5	5	5	5	6	6	6																																																																																																		
5:	6	6	6	6	6	6	7	7	7	7	7																																																																																																		
6:	7	7	7	7	7	7	7	7	7	7	7																																																																																																		
d1:	d2	0	1	2	3	4	5	6	7	8	9																																																																																																		

	<pre> 0: 0 0 0 0 0 0 0 0 0 0 0 0 1: 0 0 0 0 0 0 0 0 0 0 0 0 2: 0 0 0 0 0 0 0 0 0 0 0 0 3: 0 0 0 0 0 0 0 0 0 0 0 0 4: 0 0 0 0 0 0 0 0 0 0 0 0 5: 0 0 0 0 0 0 0 0 0 0 0 0 6: 0 0 0 0 Default DSCP-TO-DSCP Map d1: d2 0 1 2 3 4 5 6 7 8 9 0: 0 1 2 3 4 5 6 7 8 9 1: 10 11 12 13 14 15 16 17 18 19 2: 20 21 22 23 24 25 26 27 28 29 3: 30 31 32 33 34 35 36 37 38 39 4: 40 41 42 43 44 45 46 47 48 49 5: 50 51 52 53 54 55 56 57 58 59 6: 60 61 62 63 </pre>
Mode	Global Mode.
Usage	INTP means the chip internal priority setting. Because of the internal DSCP value has 64 and the chip internal priority (queue) only has 8, the dscp-intp mapping need 8 continuum internal dscp mapping to the same INTP.
Example	<p>Setting the CoS-to-INTP mapping value to the default 0 8 16 24 32 40 48 56 to 0 1 2 3 4 5 6 7.</p> <pre>Switch(config)#mls qos map cos-intp 0 1 2 3 4 5 6 7</pre>

mls qos queue algorithm

Syntax	mls qos queue algorithm (sp wrr wdrr) no mls qos queue algorithm
Parameter	sp : The strict priority, the queue number of bigger, then the priority is higher. wrr : Select wrr algorithm wdrr : Select wdrr algorithm.
Default	wrr
Mode	Port Configuration Mode.
Usage	After configure this command, the queue management algorithm is set.
Example	<p>Setting the queue management algorithm as sp.</p> <pre>switch#config Switch(config)#interface ethernet 1/0/1 Switch(config-if-ethernet1/0/1)#mls qos queue algorithm sp</pre>

mls qos queue wdrr weight

Syntax	mls qos queue wdrr weight <weight1..weight8> no mls qos queue wdrr weight
Parameter	<weight1..weight8> : defines the queue weight in Kbytes. For WDRR algorithm, this configuration is valid, but for SP algorithm, it is invalid. When the weight is 0, this queue adopts SP algorithm to manage, and WDRR algorithm turns into SP+WDRR algorithm. Range: 0-32767.
Default	The queue weight is 10 20 40 80 160 320 640 1280.
Mode	Port Configuration Mode.
Usage	If the queue weight is configured as 0, it uses SP algorithm to manage, while WRR turns into SWDRR. When removing the queue, the system will manage SP queue at first, then manage WDRR queue, SP queue executes the strict priority management mode, WDRR queue executes the weight rotation management mode.
Example	Configure the queue weight as 10 10 20 20 40 40 80 80. Switch(interface-ethernet1/0/1)#mls qos queue wdrr weight 10 10 20 20 40 40 80 80

mls qos queue wrr weight

Syntax	mls qos queue wrr weight <weight1..weight8> no mls qos queue wrr weight
Parameter	<weight1..weight8> : defines the queue weight, range: 0-127.
Default	The queue weight is 1 2 3 4 5 6 7 8.
Mode	Port Configuration Mode.
Usage	If the queue weight is configured as 0, it uses SP algorithm to manage, while WRR turns into SWDRR. When removing the queue, the system will manage SP queue at first, then manage WDRR queue, SP queue executes the strict priority management mode, WDRR queue executes the weight rotation management mode.
Example	Configure the queue weight as 127 8 9 6 3 4 2 0 Switch(interface-ethernet1/0/1)#mls qos queue wrr weight 127 8 9 6 3 4 2 0

mls qos queue bandwidth

Syntax	mls qos queue <queue-id> bandwidth <maximum-bandwidth> no mls qos queue <queue-id> bandwidth
Parameter	<queue-id> : queue ID to configure the bandwidth guarantee, the different chip supports the different queue count, the range is different too, and the ranging from 1 to 8. <maximum-bandwidth> : maximum-bandwidth, ranging from 0 to 128000, when input 0, it means the max-bandwidth function is not take effect. The minimum-bandwidth must not bigger than maximum-bandwidth.
Default	The queue bandwidth have no guarantee.
Mode	Port Configuration Mode.
Usage	The minimum-bandwidth guarantee and maximum-bandwidth limit can be configured at the different or same queue. The queue bandwidth pledge for egress is relative to management mode, for example: one port is the strict priority-queue, the highest priority is queue 8 now, and it will satisfy this queue traffic when block is happened. But if user want the lower priority of queue having bandwidth, it can remain bandwidth via this command, the lower priority queue's minimum-bandwidth will be satisfied at first, then the excess bandwidth is managed according to SP.
Example	Configure the maximum-bandwidth is 128kbps for ethernet1/0/2 queue1. Switch(config)#interface ethernet 1/0/2 Switch(config-if-ethernet1/0/2)# mls qos queue 1 bandwidth 128

mls qos trust

Syntax	mls qos trust (cos dscp) no mls qos trust (cos dscp)
Parameter	dscp : configures the port to trust DSCP status cos : configures the COS port to trust status.
Default	The default is trust COS value.
Mode	Port Configuration Mode.
Usage	Configures the current port trust; the no command disables the current trust status of the port. trust dscp mode: Set the intp field based dscp-to-intp mapping. trust cos mode: Set the intp field based cos-to-intp mapping.
Example	Set trust dscp of port 1/0/1, not trust cos. Switch(config)#interface ethernet 1/0/1 Switch(config-if-ehternet1/1)# mls qos trust dscp Switch(config-if-ehternet1/1)#no mls qos trust cos

policy burst

Syntax	policy burst <burst_group><normal_burst_bytes>
Parameter	<burst_group> : burst_group id ranges from 1 to 2. <normal_burst_bytes> : The committed burst size – CBS (Committed Burst Size), in byte, ranging from 1 to 8192. When the configured CBS value exceeds the max limit of the chip, configure the hardware with max number supported by the chip without any CLI prompt.
Default	The default of normal_burst_bytes is 1024.
Mode	Global Mode.
Usage	Configure burst-group in global mode and it supports 2 burst-group, then it can use burst-group in strategy classify table mode. It can return default configuration by set 1024 as default value.
Example	Set burst-group 1 to define CBS as 512 bits Switch(config)#policy burst 1 512

policy

Syntax	policy <bits_per_second> burst-group <burst-group-id> no policy
Parameter	<bits_per_second> : The committed information rate – CIR (Committed Information Rate), in Kbps, ranging from 1 to 10000000; <burst-group-id> : It is CBS burst-group id and it ranges from 1 to 2.
Default	No policy action.
Mode	Policy class map configuration mode.
Usage	Supports non-aggregate policy command of double color, the no command delete mode configuration. Configure information rate in policy class map configuration mode. Do not support the color configuration and the default green packets are transmit, red packets drop.
Example	Set information rate 1000 in policy class map configuration mode, the CBS is 512, the more than cir rate will send and do nothing for packets. Switch(config)#policy burst 1512 Switch(config)#class-map cm Switch(config-classmap-cm)#match cos 0 Switch(config-classmap-cm)#exit Switch(config)#policy-map 1 Switch(config-policymap-1)#class cm Switch(config-policymap-1-class-cm)# policy 1000 burst-group 1

policy aggregate

Syntax	policy aggregate <aggregate-policy-name> no policy aggregate <aggregate-policy-name>
Parameter	<aggregate-policy-name> : is the policy set name.
Default	No policy is configured by default.
Mode	Policy class map configuration mode.
Usage	Police Map reference aggregate policy, applies an aggregate policy to classified traffic; the no command deletes the specified aggregate policy. The same policy set can be referred by different policy class maps.

Example	Create class-map, the match rule is the cos value is 0; policy-map is 1, enter the policy map mode, set the Policy and choose the color policy for the current list. Switch(config)#class-map cm Switch(config-classmap-cm)#match cos 0 Switch(config-classmap-cm)#exit Switch(config)#policy-map 1 Switch(config-policymap-1)#class cm Switch(config-policymap-1-class-cm)#policy aggregate color
----------------	--

policy-map

Syntax	policy-map <policy-map-name> no policy-map <policy-map-name>
Parameter	<policy-map-name> : policy map name.
Default	No policy map is configured by default.
Mode	Global Mode.
Usage	Creates a policy map and enters the policy map mode; the " no policy-map <policy-map-name> " command deletes the specified policy map. Policy class map operation can be done in policy map configuration mode.
Example	Creating and deleting a policy map named "p1". Switch(config)#policy-map p1 Switch(config-policymap-p1)#exit Switch(config)#no policy-map p1

service-policy input

Syntax	service-policy input <policy-map-name> no service-policy input {<policy-map-name>}
Parameter	input <policy-map-name> : applies the specified policy map to the ingress direction of switch port. no command will delete all the policy maps applied on the ingress direction of the port if there is not the specified policy map name.
Default	No policy map is bound to port by default.
Mode	Port Configuration Mode.

Usage	Applies a policy map to the specified port; the no command deletes the specified policy map applied to the port or deletes all the policy maps applied on the ingress direction of the port . Only one policy map can be applied to each direction of each port or VLAN interface.
Example	Bind policy p1 to ingress Ethernet port1/1. Switch(config)#interface ethernet 1/0/1 Switch(config-if-ethernet1/0/1)#service-policy input p1

service-policy input vlan

Syntax	service-policy input <policy-map-name> vlan <vlan-list> no service-policy input {<policy-map-name>} vlan < vlan-list>
Parameter	input <policy-map-name> : input <policy-map-name> applies the specified policy map to the ingress direction of switch VLAN interface. vlan < vlan-list> : vlan <vlan-list>the vlan list of binding policy map.
Default	No policy map is bound to VLAN interface by default.
Mode	Global Mode.
Usage	Applies a policy map to the specified VLAN interface; the no command deletes the specified policy map applied to the VLAN interface or deletes all the policy maps applied in the ingress direction of the vlan interface. Only one policy map can be applied to each direction of each port or VLAN interface.
Example	Bind policy p1 to ingress of VLAN interface 2-4,6 Switch(config)#service-policy input p1 vlan 2-4;6

set

Syntax	set (ip dscp <new-dscp> ip precedence <new-precedence> internal priority <new-inp> drop precedence <new-dp> cos <new-cos>) no set (ip dscp ip precedence internal priority drop precedence cos)
Parameter	ip dscp <new-dscp> : new DSCP value, do not distinguish v4 and v6. ip precedence <new-precedence> : new IP Precedence. cos <new-cos> : new IP Precedence.
Default	Not assigning by default.

Mode	Policy Class-map Mode.
Usage	Assigns a new DSCP, IP Precedence for the classified traffic; the no form of this command delete assigning the new values. Only the classified traffic which matches the matching standard will be assigned with the new values.
Example	Set the IP Precedence of the packets matching c1 class rule to 3. <pre>Switch(config)#policy-map p1 Switch(Config-PolicyMap-p1)#class c1 Switch(Config-PolicyMap-p1-Class-c1)#set ip precedence 3 Switch(Config-PolicyMap-p1-Class-c1)#exit Switch(Config-PolicyMap-p1)#exit</pre>

show class-map

Syntax	show class-map [<class-map-name>]								
Parameter	i[<class-map-name>]: class map name								
Default	None.								
Mode	Admin Mode.								
Usage	Displays all configured class-map or specified class-map information.								
Example	Switch#show class-map Class map name:cm, used by 1 time(s) match cos: 0 Class map name:color, used by 0 time(s) match cos: 0 <table border="1" data-bbox="452 1493 1230 1695"> <tr> <td>Displayed information</td> <td>Explanation</td> </tr> <tr> <td>Class map name:c1</td> <td>Name of the Class map</td> </tr> <tr> <td>used by 1 times</td> <td>Used times</td> </tr> <tr> <td>match acl name:1</td> <td>Classifying rule for the class map</td> </tr> </table>	Displayed information	Explanation	Class map name:c1	Name of the Class map	used by 1 times	Used times	match acl name:1	Classifying rule for the class map
Displayed information	Explanation								
Class map name:c1	Name of the Class map								
used by 1 times	Used times								
match acl name:1	Classifying rule for the class map								

show policy-map

Syntax	show policy-map [<policy-map-name>]										
Parameter	<policy-map-name> : policy map name										
Default	None.										
Mode	Admin Mode.										
Usage	Displays all configured policy-map or specified policy-map information.										
Example	Switch#show policy-map Policy Map 1, used by 0 time(s) Class Map name: cm Policy Map p1, used by 0 time(s) Class Map name: c1 drop set ip precedence 3 policy CIR: 2000 CBS: 512 conform-action: transmit exceed-action: drop <table border="1" data-bbox="452 1111 1230 1336"> <tr> <th>Displayed information</th> <th>Explanation</th> </tr> <tr> <td>Policy map name:c1</td> <td>Name of policy map</td> </tr> <tr> <td>Class Map name: c1</td> <td>Class Map name</td> </tr> <tr> <td>policy 20000 512</td> <td>Policy implemented</td> </tr> <tr> <td>used by 0 port</td> <td>Number of port that use the policy</td> </tr> </table>	Displayed information	Explanation	Policy map name:c1	Name of policy map	Class Map name: c1	Class Map name	policy 20000 512	Policy implemented	used by 0 port	Number of port that use the policy
Displayed information	Explanation										
Policy map name:c1	Name of policy map										
Class Map name: c1	Class Map name										
policy 20000 512	Policy implemented										
used by 0 port	Number of port that use the policy										

show mls qos interface

Syntax	show mls qos {interface [<interface-id>] [policy queuing] vlan <vlan-id>} [begin include exclude <regular-expression>]
Parameter	<interface-id> : port ID <vlan-id> : VLAN ID <regular-expression> : Regular expression
Default	None.
Mode	Admin Mode.
Usage	Displays QoS configuration information on a port. There is only red or green when packets passing policy. In the print information, in packets means classify packets numbers and not supports the statistic information of color.

Example	Switch#show mls qos interface ethernet 1/0/1																										
	Ethernet1/0/1: Default COS: 0 Trust: DSCP Attached Policy Map for Ingress: p1																										
	Egress Internal-Priority-TO-Queue map: INTP: 0 1 2 3 4 5 6 7 ----- Queue: 0 1 2 3 4 5 6 7																										
	Queue Algorithm: WRR Queue weights: Queue 1 2 3 4 5 6 7 8 ----- WrrWeight 1 2 3 4 5 6 7 8 WdrrWeight 10 10 20 20 40 40 80 80																										
	Bandwidth Guarantee Configuration: Queue 1 2 3 4 5 6 7 8 ----- MinBW(K) 0 0 0 0 0 0 0 0 MaxBW(K) 0 0 0 0 0 0 0 0																										
	<table border="1"> <thead> <tr> <th>Displayed information</th><th>Explanation</th></tr> </thead> <tbody> <tr> <td>Ethernet1/0/1</td><td>Port name</td></tr> <tr> <td>default cos:0</td><td>Default CoS value of the port</td></tr> <tr> <td>Trust: COS</td><td>The trust state of the port</td></tr> <tr> <td>Attached Policy Map for Ingress: p1</td><td>Policy name bound to port</td></tr> <tr> <td>ClassMap</td><td>ClassMap name</td></tr> <tr> <td>classified</td><td>Total data packets match this ClassMap. If there is no Accounting for Class Map, show NA</td></tr> <tr> <td>in-profile</td><td>Total in-profile data packets match this ClassMap. If there is no Accounting for Class Map, show NA</td></tr> <tr> <td>out-profile</td><td>Total out-profile data packets match this ClassMap. If there is no Accounting for Class Map, show NA</td></tr> <tr> <td>Internal-Priority-TO-Queue map::</td><td>Internal-Priority to queue mapping</td></tr> <tr> <td>Queue Algorithm:</td><td>WRR, WDDR or PQ queue out method</td></tr> <tr> <td>Queue weights</td><td>Queue weights Configuration</td></tr> <tr> <td>Bandwidth Guarantee Configuration</td><td>Bandwidth Guarantee Configuration</td></tr> </tbody> </table>	Displayed information	Explanation	Ethernet1/0/1	Port name	default cos:0	Default CoS value of the port	Trust: COS	The trust state of the port	Attached Policy Map for Ingress: p1	Policy name bound to port	ClassMap	ClassMap name	classified	Total data packets match this ClassMap. If there is no Accounting for Class Map, show NA	in-profile	Total in-profile data packets match this ClassMap. If there is no Accounting for Class Map, show NA	out-profile	Total out-profile data packets match this ClassMap. If there is no Accounting for Class Map, show NA	Internal-Priority-TO-Queue map::	Internal-Priority to queue mapping	Queue Algorithm:	WRR, WDDR or PQ queue out method	Queue weights	Queue weights Configuration	Bandwidth Guarantee Configuration	Bandwidth Guarantee Configuration
Displayed information	Explanation																										
Ethernet1/0/1	Port name																										
default cos:0	Default CoS value of the port																										
Trust: COS	The trust state of the port																										
Attached Policy Map for Ingress: p1	Policy name bound to port																										
ClassMap	ClassMap name																										
classified	Total data packets match this ClassMap. If there is no Accounting for Class Map, show NA																										
in-profile	Total in-profile data packets match this ClassMap. If there is no Accounting for Class Map, show NA																										
out-profile	Total out-profile data packets match this ClassMap. If there is no Accounting for Class Map, show NA																										
Internal-Priority-TO-Queue map::	Internal-Priority to queue mapping																										
Queue Algorithm:	WRR, WDDR or PQ queue out method																										
Queue weights	Queue weights Configuration																										
Bandwidth Guarantee Configuration	Bandwidth Guarantee Configuration																										

Switch(config)#show mls qos interface ethernet 1/0/1 queuing

Ethernet1/0/1:

Egress Internal-Priority-TO-Queue map:

INTP: 0 1 2 3 4 5 6 7

Queue: 0 1 2 3 4 5 6 7

Queue Algorithm: WRR

Queue weights:

Queue 1 2 3 4 5 6 7 8

WrrWeight 1 2 3 4 5 6 7 8

WdrrWeight 10 10 20 20 40 40 80 80

Bandwidth Guarantee Configuration:

Queue 1 2 3 4 5 6 7 8

MinBW(K) 0 0 0 0 0 0 0 0

MaxBW(K) 0 0 0 0 0 0 0 0

Displayed information	Explanation
Internal-Priority-TO-Queue map::	Internal-Priority to queue mapping
Queue Algorithm:	WRR, WDDR or PQ queue out method
Queue weights	Queue weights configuration
Bandwidth Guarantee Configuration	Bandwidth Guarantee Configuration

Switch # show mls qos interface ethernet 1/0/1 policy

Ethernet1/0/1:

Attached Policy Map for Ingress: p1

Displayed information	Explanation
Ethernet1/0/1	Port name
Attached Policy Map for Ingress: p1	Policy name bound to port
ClassMap	ClassMap name
classified	Total data packets match this ClassMap.
in-profile	Total in-profile data packets match this ClassMap.
out-profile	Total out-profile data packets match this ClassMap.

show mls qos in (interface <interface-name> policy) | (vlan <vlan-id>)

Syntax	show mls qos in (interface <interface-name> policy) (vlan <vlan-id>)
Parameter	<interface-name> : port name. <vlan-id> : VLAN ID
Default	None.
Mode	Admin Mode.
Usage	Show the policy configuration information in direction of port or vlan. Show the policy configuration information in direction.
Example	Show the policy configuration information in direction. Switch#show mls qos in interface ethernet1/0/1 policy Ethernet1/0/1: Attached Policy Map for Ingress: p1

show mls qos maps

Syntax	show mls qos maps [cos-intp cos-dp dscp-intp dscp-dp dscp-dscp] [begin include exclude <regular-expression>]
Parameter	cos-intp : The mapping from ingress L2 CoS to internal priority. cos-dp : The mapping from ingress L2 CoS to drop priority. dscp-intp : The mapping from ingress DSCP to internal priority. dscp-dp : The mapping from ingress DSCP to drop priority. dscp-dscp : The mapping from outgress internal to DSCP priority.
Default	None.
Mode	Admin and Configuration Mode.
Usage	Displays the map configuration information of QoS.
Example	Display configuration information of the mapping table. Switch#show mls qos maps Ingress COS-TO-Internal-Priority map: COS: 0 1 2 3 4 5 6 7 ----- INTP: 0 1 2 3 4 5 6 7 Ingress DSCP-TO-Internal-Priority map: d1:d2 0 1 2 3 4 5 6 7 8 9

0:	7 1 7 7 7 0 7 7 7 1
1:	1 1 1 1 1 1 2 1 2 2
2:	2 2 2 2 3 1 3 3 3 3
3:	3 3 4 1 4 4 4 4 4 4
4:	5 1 5 5 5 5 5 5 6 1
5:	6 6 6 6 6 6 7 1 7 7
6:	7 7 7 7

Ingress COS-TO-Drop-Precendence map:
COS: 0 1 2 3 4 5 6 7

DP: 0 0 0 0 0 0 0 0

Ingress DSCP-TO-DSCP map:
d1:d2 0 1 2 3 4 5 6 7 8 9
0: 0 1 2 3 4 5 6 7 8 9
1: 10 11 12 13 14 15 16 17 18 19
2: 20 21 22 23 24 25 26 27 28 29
3: 30 31 32 33 34 35 36 37 38 39
4: 40 41 42 43 44 45 46 47 48 49
5: 50 51 52 53 54 55 56 57 58 59
6: 60 61 62 63

Ingress DSCP-TO-Drop-Precendence map:
d1:d2 0 1 2 3 4 5 6 7 8 9
0: 0 0 0 0 0 0 0 0 0 0
1: 0 0 0 0 0 0 0 0 0 0
2: 0 0 0 0 0 0 0 0 0 0
3: 0 0 0 0 0 0 0 0 0 0
4: 0 0 0 0 0 0 0 0 0 0
5: 0 0 0 0 0 0 0 0 0 0
6: 0 0 0 0p1

show mls qos vlan

Syntax	show mls qos vlan <v-id>
Parameter	<v-id> : VLAN ID
Default	None.
Mode	Admin Mode.
Usage	Display configuration information of the QOS VLAN.
Example	Switch#show mls qos vlan 1 Vlan 1: Attached Policy Map for Ingress: 1 Classmap classified(in packets) c1 0 Rule ID classified(in packets)

show mls qos aggregate-policy

Syntax	show mls qos aggregate-policy [<aggregate-policy-name>]						
Parameter	<aggregate-policy-name> : aggregate policy name						
Default	None.						
Mode	Admin mode and configuration mode.						
Usage	Display all configured aggregate-policy or appointed aggregate-policy information.						
Example	Switch#show mls qos aggregate-policy a2 aggregate policy a2 CIR: 1000 CBS: 1024 conform-action: transmit exceed-action: drop Not used by any policy map <table border="1" data-bbox="389 1740 1278 2010"> <tr> <th>Displayed information</th> <th>Explanation</th> </tr> <tr> <td>aggregate policy a2 CIR: 1000 CBS: 1024 conform-action: transmit exceed-action: drop</td> <td>The configuration of aggregate policy.</td> </tr> <tr> <td>Not used by any Policy Map</td> <td>The referenced times of aggregate policy.</td> </tr> </table>	Displayed information	Explanation	aggregate policy a2 CIR: 1000 CBS: 1024 conform-action: transmit exceed-action: drop	The configuration of aggregate policy.	Not used by any Policy Map	The referenced times of aggregate policy.
Displayed information	Explanation						
aggregate policy a2 CIR: 1000 CBS: 1024 conform-action: transmit exceed-action: drop	The configuration of aggregate policy.						
Not used by any Policy Map	The referenced times of aggregate policy.						

transmit

Syntax	transmit no transmit
Parameter	none
Default	Do not set the action.
Mode	Policy class map configuration mode.
Usage	Send the packet directly after configure this command.
Example	Send the packet which satisfy c1. <pre>Switch#config Switch(config)#policy-map p1 Switch(config-policymap-p1)#class c1 Switch(config-policymap-p1-class-c1)#transmit Switch(config-policymap-p1-class-c1)#exit Switch(config-policymap-p1)#+</pre>

access-group redirect to interface ethernet

Syntax	access-group <aclname> redirect to interface [ethernet] <IFNAME> no access-group <aclname> redirect
Parameter	<aclname> : name of the flow , only supports digital standard IP ACL, digital extensive IP ACL, nomenclatural standard IP ACL, nomenclatural extensive IP ACL, digital standard MAC ACL, digital extensive MAC ACL, nomenclatural standard MAC ACL, nomenclatural extensive MAC, digital standard IPv6 ACL, and nomenclatural standard IPv6 ACL. Parameters of Time range and Port range cannot be set in ACL; the type of ACL should be Permit. <IFNAME> : the destination port of redirection.
Default	None.
Mode	Port Configuration Mode.
Usage	Specifies flow-based redirection; “no access-group <aclname> redirect” command is used to delete flow-based redirection. Flow-based redirection function enables the switch to transmit the data frames meeting some special condition to another specified port. Notice: Redirect does not support redirect flow to the port.

Example	Redirecting the frames whose source IP is 192.168.1.111 received from port 1 to port 6
	<pre>Switch(config)#access-list 1 permit host 192.168.1.111 Switch(config)# interface ethernet 1/0/1 Switch(config-if-ethernet1/0/1)#access-group 1 redirect to interface ethernet 1/0/6</pre>

show flow-based-redirect

Syntax	show flow-based-redirect [interface [etherent] <IFNAME>]
Parameter	<IFNAME> : display the information of the flow-based redirection configured in the ports listed in the interface-list.
Default	None.
Mode	Admin Mode and Configuration Mode.
Usage	This command is used to display the information of current flow-based redirection in the system/port.
Example	Switch(config)#show flow-based-redirect Flow-based-redirect config on interface Ethernet1/0/1: RX flow (access-list 1) is redirected to interface Ethernet1/0/6

add

Syntax	add s-vid <new-vid> no add s-vid
Parameter	s-vid <new-vid> : s-vid <new-vid> appointed VID of tunnel VLAN Tag.
Default	The default is not add tag.
Mode	Policy classify table configuration mode.
Usage	Add specified tunnel tag for data packets of mapped classify table, the no command cancels the configuration. After configuring the command, add appointed tunnel tag or inner tag for packets of mapping classify table. When use QinQ function, the data packets that sent only have inner VLAN Tag or no Tag, it needs add s-vid commands to add appointed tunnel VLAN Tag, otherwise data do not have tunnel VLAN in switch.

Example	Add a VLAN Tag that VID is 2 to satisfied c1 classify rule packets. <pre>Switch#config Switch(config)#policy-map p1 Switch(config-policymap-p1)#class c1 Switch(config-policymap-p1-class-c1)#add s-vid 2</pre>
----------------	--

service-policy

Syntax	service-policy <policy-map-name> in no service-policy <policy-map-name> in
Parameter	<policy-map-name> : The specified policy-map name of flexible QinQ.
Default	No policy map is bound to port.
Mode	Port Configuration Mode.
Usage	Binds the specified policy of flexible QinQ to the ingress of the port, the no command cancels the binding. Only one policy map can be bound to each port, the function takes effect after the policy map is bound to a port. At present, do not support the configuration with add command and delete command in policy.
Example	Apply policy-map p1 (p1 corresponds with the action that modify s-vid) to Ethernet port 1/0/1 for flexible QinQ. <pre>Switch(config-if-ethernet1/0/1)#dot1q-tunnel enable Switch(config-if-ethernet1/0/1)#</pre>

set

Syntax	set {s-vid <new-vid> cos <cos-list> drop-precedence <dp-list> internal-priority <inp-list> ip {dscp <dscp-list> precedence <pri-list>} s-tpid <tpid-list> } no set{s-vid cos drop-precedence internal-priority ip {dscp precedence} s-tpid }
Parameter	<new-vid> : modify tunnel VID of VLAN Tag <cos-list> : modify cos value of packets <dp-list> : modify drop priority <inp-list> : modify inner priority <dscp-list><pri-list> : modify ip dscp value or precedence value <tpid-list> : modify tunnel tpid value of packets

Default	Do not modify the value.
Mode	Policy class map configuration mode.
Usage	Assigns the new cos and vid value to the packets which match the class map, no command cancels the operation. Only modify the new value again for the classified flow that correspond the match standard.
Example	<p>Set an external VLAN Tag' VID as 3 for the packet which satisfy c2 class rule.</p> <pre>Switch(config)#policy-map p1 Switch(config-policymap-p1)#class c2 Switch(config-policymap-p1-class-c2)#set s-vid 3 Switch(config-policymap-p1-class-c2)#exit</pre>